HP Color LaserJet 2820/2830/2840

Service Manual

For the complete PDF manual please visit www.LaserPros.com.







HP Color LaserJet 2820/2830/2840 all-in-one

Service Manual



Copyright and License

© 2004 Copyright Hewlett-Packard Development Company, LP

Reproduction, adaptation, or translation without prior written permission is prohibited, except as allowed under the copyright laws.

The information contained in this document is subject to change without notice.

The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Part number Q3948-90943

Edition 1, 12/2004

Safety information

WARNING!

Potential Shock Hazard

Always follow basic safety precautions when using this product to reduce risk of injury from fire or electric shock.

Read and understand all instructions in the device user guide.

Observe all warnings and instructions marked on the product.

Use only a grounded electrical outlet when connecting the device to a power source. If you do not know whether the outlet is grounded, check with a qualified electrician.

Do not touch the contacts on the end of any of the sockets on the device. Replace damaged cords immediately.

Unplug this product from wall outlets before cleaning.

Do not install or use this product near water or when you are wet.

Install the product securely on a stable surface.

Install the product in a protected location where no one can step on or trip over the power cord and where the power cord will not be damaged.

If the product does not operate normally, see the online User Guide.

Refer all servicing questions to qualified personnel.

Information regarding FCC Class B, Parts 15 and 68 requirements can be found in the device user guide.

Trademark Credits

Adobe Photoshop and PostScript are trademarks of Adobe Systems Incorporated.

Corel is a trademark or registered trademark of Corel Corporation or Corel Corporation Limited.

Microsoft, Windows, and Windows NT are U.S. registered trademarks of Microsoft Corporation.

UNIX is a registered trademark of The Open Group.

ENERGY STAR® and the ENERGY STAR® logo are U.S. registered marks of the United States Environmental Protection Agency.



Table of contents

1 Product information

| Chapter contents | |
|---|----|
| Device configurations | 2 |
| HP Color LaserJet 2820 all-in-one | |
| HP Color LaserJet 2830 all-in-one | 2 |
| HP Color LaserJet 2840 all-in-one | 3 |
| Device features | 4 |
| Device parts | 6 |
| Front view | 6 |
| Back view | 6 |
| Model and serial numbers | 7 |
| Software components | 12 |
| System requirements | 12 |
| Software and supported operating systems | 12 |
| Software tips | |
| Gaining access to the device features | 14 |
| Obtaining the latest printing software | 14 |
| Other print system software | |
| Software for Windows | 15 |
| Printer drivers | 15 |
| Using Help | |
| Software for Macintosh | |
| HP Director | |
| PPDs (Mac OS 9.2.2) | |
| PDEs (Mac OS 10.2 and 10.3) | |
| HP Toolbox | |
| Embedded Web server (EWS) | |
| Software installation | |
| Typical installation | |
| Minimum installation | |
| Uninstalling the printing software | |
| Using Add or Remove Programs to uninstall | |
| Uninstalling software for Macintosh | |
| Specifications | |
| Media specifications | |
| Supported media weights and sizes | |
| General guidelines | |
| Paper and print media | |
| Special media print speeds | |
| Printing and storage environment | 26 |

ENWW

| | Envelope storage | 27 |
|---------------------------|--|----|
| | Envelope construction | 27 |
| | Envelopes with double side-seams | 28 |
| | Envelopes with adhesive strips or flaps | 28 |
| Labels | S | 28 |
| Trans | parencies | 29 |
| Hewlett-Packard | d limited warranty statement | 30 |
| Print Cartridge a | and Imaging Drum Limited Warranty Statement | 31 |
| Print-cartridge in | nformation | 32 |
| Refille | ed print cartridges | 32 |
| HP La | aserJet printing supplies | 32 |
| | rinting Supplies Returns and Recycling Program information | |
| | ements | |
| FCC F | Requirements (United States) | 33 |
| Telepl | hone Consumer Protection Act (United States) | 34 |
| EU sta | atement for telecom operation | 34 |
| | Zealand telecom statements | |
| IC CS | S-03 requirements | 34 |
| | rations of conformity | |
| | Declaration of conformity | 36 |
| | Declaration of conformity | 36 |
| Count | try-/region-specific safety statements | 38 |
| | Laser safety statement | 38 |
| | Canadian DOC statement | 38 |
| | Korean EMI statement | 38 |
| | Finnish laser statement | 39 |
| | | |
| 2 Installation and operat | ion | |
| - | S | 41 |
| • | onment | |
| | | |
| - | atures | |
| • | | |
| | | |
| | utput bin | |
| - | output bin | |
| | | |
| _ | ng tray 1 | |
| | ng optional tray 2 | |
| | ng documents to scan | |
| | | |
| | ng HP Toolbox | |
| | s tab | |
| | ab | |
| | to tab | |
| | leshooting tab | |
| | mentation tab | |
| | e Settings pages | |
| | System Settings tab | |
| | | |

Envelopes......27

| | Print Settings tab | b |
|-----|--|----------------|
| | Fax Settings tab | 57 |
| | Copy Settings tab | 57 |
| | Network Settings tab | 57 |
| | HP Toolbox links | 58 |
| | Other links | 58 |
| | Embedded Web server | |
| | Features | |
| 3 1 | Maintenance | |
| | Chapter contents | 6´ |
| | Life expectancies of components | |
| | Cleaning the device | |
| | Cleaning the device exterior and scanner | |
| | Cleaning the paper path | |
| | Managing supplies | |
| | Supplies life | |
| | Checking and ordering supplies | |
| | To check status and order supplies using the control panel | |
| | To check status and order supplies using the HP Toolbox | |
| | Storing supplies | |
| | Replacing and recycling supplies | |
| | | |
| | HP policy for non-HP supplies | |
| | Resetting the device for non-HP supplies HP fraud hotline | |
| 4 1 | Theory of operation Chapter contents | 7′ |
| | Introduction | 72 |
| | Engine control system | 76 |
| | Basic sequence of operation | |
| | Power-on sequence | 78 |
| | Motors and fans | 79 |
| | Laser/scanner system | 80 |
| | Pickup and feed system | |
| | Optional tray 2 | 83 |
| | Jam detection | |
| | Photosensors and switches | 8 |
| | Solenoids and clutches | |
| | Printed circuit assemblies | |
| | Image-formation system | 9 ² |
| | Image-formation process | |
| | Latent-image-formation stage | |
| | Step 1: primary charging | |
| | Step 2: laser-beam exposure | |
| | Developing stage | |
| | Step 3: auxiliary developing | |
| | Step 4: developing | |
| | Transfer stage | |
| | Step 5: primary transfer | |
| | | |

ENWW

| Step 6: secondary transfer | 96 |
|---|-----|
| Step 7: separation | 97 |
| Fusing stage | 98 |
| Step 8: fusing | 98 |
| Step 9: roller charging (auxiliary transfer belt cleaning roller) | 98 |
| Step 10: roller charging (transfer-belt cleaning roller) | 99 |
| Step 11: transfer belt cleaning | 99 |
| Step 12: drum cleaning | 100 |
| Print cartridge | 102 |
| Imaging-drum E-label | 103 |
| Scanner and ADF functions and operation | 104 |
| Scanner functions | 104 |
| Scanner operation | 104 |
| ADF operation | 105 |
| ADF paper path and ADF sensors | 105 |
| ADF jam detection | |
| Fax functions and operation | |
| PSTN operation | |
| To receive faxes when you hear fax tones | |
| The fax subsystem | |
| Formatter in the fax subsystem | |
| LIU in the fax subsystem | |
| Safety isolation | |
| Safety-protection circuitry | |
| Data path | |
| Hook state | |
| Downstream current detection | |
| Hook switch control | |
| Ring detect | |
| Line current control | |
| Billing (metering) tone filters | |
| Fax page storage in flash memory | |
| Stored fax pages | |
| Advantages of flash memory storage | 111 |
| 5 Book along the control of | |
| 5 Removal and replacement Chapter contents | 112 |
| Removal and replacement strategy | |
| Required tools | |
| Screws | |
| Electrostatic discharge | |
| Before performing service | |
| After performing service | |
| Post-service tests | |
| Test 1 (print-quality test) | |
| Test 2 (copy-quality test) | |
| Test 3 (fax-quality test) | |
| Test 4 (memory-card test) | |
| Parts removal order | |
| User-replaceable parts | |
| Oct. Topiaooabio parto | 119 |

vi ENWW

| | Replacing the print cartridges | 119 |
|--------|---|-----|
| | Replacing the imaging drum | 121 |
| | Replacing the ADF | 123 |
| | Replacing the ADF pickup-roller assembly | 124 |
| | Removing the ADF separation pad | 130 |
| | Replacing the ADF scanner glass | 132 |
| | Replacing the fuser assembly | 133 |
| | Replacing the control-panel bezel | 134 |
| | Replacing the tray 1 pickup roller and separation pad | 135 |
| Covers | 3 | 142 |
| | Removing the left cover | 142 |
| | Removing the right cover | 145 |
| | Removing the right rear cover | 146 |
| | Removing the scanning assembly | 148 |
| | Removing the left rear cover | 153 |
| | Removing the left upper cover | 153 |
| | Removing the right upper cover | 155 |
| | Replacing the memory-card assembly (HP Color LaserJet 2840 all-in-one only) | 157 |
| | Removing the input/output (I/O) cover | 158 |
| | Removing the back cover | 161 |
| | Removing the top cover assembly | 162 |
| | Removing the upper multipurpose cover | 165 |
| | Removing the density sensor and top-of-page sensor | 167 |
| | Removing the multipurpose roller cover | 168 |
| | Removing the lower multipurpose cover | 169 |
| Main a | ssemblies | 172 |
| | Removing the control panel | |
| | Removing the left support assembly | |
| | Removing the right support assembly | |
| | Removing the laser/scanner assembly | |
| | Removing the transfer-roller plate | |
| | Removing the transfer roller | |
| | Removing the formatter assemblies | |
| | Removing the formatter cage | |
| | Removing the formatter and line interface unit (LIU) | |
| | Removing the E-label reader (for imaging-drum E-labels) | |
| | Removing the DC controller | |
| | Removing the top plate | |
| | Removing the gear assembly | |
| | Removing the waste-toner sensor | |
| | Removing the rotary-drive assembly | |
| | Removing the print-cartridge carousel | |
| | Aligning the carousel gears | |
| | Removing the registration-roller assembly | |
| | Removing the toner-catch tray | |
| | Removing the feed-drive shaft and belts | |
| | Removing the power supply cover plate | |
| | Removing the paper-top sensor | |
| | Removing the fuser-wrap sensor | |
| Motors | and fans | 222 |

ENWW vii

| Removing the fuser motor | 222 |
|---|---------------------------|
| Removing the carousel-engagement motor | |
| Removing the air duct and fan | |
| Printed circuit assemblies (PCAs) | |
| Removing the sub-high-voltage transformer PCA | |
| Removing the high-voltage transformer PCA | |
| Removing the low-voltage PCA | |
| Trays | |
| Removing tray 1 (multipurpose tray) | |
| Removing optional tray 2 (250-sheet tray) | |
| | |
| Removing the optional tray 2 pickup roller | |
| Replacing the optional tray 2 separation pad | 2ან |
| 6 Troubleshooting | |
| Support strategy | 238 |
| Troubleshooting process | |
| Troubleshooting checklist | |
| Control-panel messages | |
| Alert and warning messages | |
| Critical error messages | |
| Clearing jams | |
| Media jams occur in the device | |
| Tips to avoid media jams | |
| Where to look for jams | |
| To clear a media jam inside the device | |
| To clear a media jam inside the device | |
| Media jams occur in the automatic document feeder (ADF) | |
| To clear a media jam from the automatic document | |
| Print problems | , |
| · | |
| Print quality problems | |
| Improving print quality | |
| Understanding print-quality settings | |
| | uality settings263 |
| | gs for all future jobs263 |
| Identifying and correcting print defects | |
| Print-quality checklist | |
| General print quality issues | |
| Solving issues with color documents | |
| Media-handling problems | |
| Print-media guidelines | |
| Solving print-media problems | |
| Performance problems | |
| Scan problems | |
| Solving scanned image problems | |
| Scan quality problems | 277 |
| Preventing problems | 277 |
| Solving scan-quality problems | 278 |
| Scan-specific error messages | 279 |
| Copy problems | 280 |
| Preventing problems | |

viii ENWW

| Image problems | |
|--|-----|
| Media-handling problems | 282 |
| Performance problems | 283 |
| Fax problems | 285 |
| Problems receiving faxes | 285 |
| Problems sending faxes | 287 |
| Voice call problems | 288 |
| Media-handling problems | 289 |
| Performance problems | 289 |
| Memory card problems | |
| Missing or wrong files | 291 |
| Index page not printing | 291 |
| Proof sheet not printing | |
| Proof sheet not scanning | 292 |
| Issues with photo printing | |
| Functional tests | |
| Engine test | |
| Half self-test check | |
| Heating element test | |
| Cartridge high-voltage contact test | |
| Paper-path test | |
| Service-mode functions. | |
| NVRAM initialization | |
| Secondary service menu | |
| To print secondary service reports | |
| Troubleshooting tools | |
| Device pages and reports | |
| Demo page | |
| Configuration page | |
| Supplies Status page | |
| Usage page | |
| Engine-test page | |
| Error log | |
| Fax reports | |
| Fax activity log | |
| Fax call report | |
| T.30 protocol trace | |
| HP Toolbox | |
| To view HP Toolbox | |
| Troubleshooting tab | |
| Service menu | |
| Restoring the factory-set defaults | |
| · · · · · · · · · · · · · · · · · · · | |
| Cleaning the paper path | |
| Setting the scanner bulb power save time | |
| Reducing paper curl | |
| Service-only tools | |
| Timing charts | |
| Locations of connectors | |
| DC controller connections | |
| Printer calibration | 326 |

| | Repetitive image defect ruler | 327 |
|------|--|-----|
| | Main wiring diagram | 328 |
| | Updating or recovering the firmware code | |
| | Firmware update by using flash executable | |
| | Firmware-recovery DIMM | |
| 7 P | Parts and diagrams | |
| | Chapter contents | 333 |
| | Ordering parts and supplies | 334 |
| | Parts | 334 |
| | Related documentation and software | 334 |
| | Supplies | 334 |
| | Accessories | 335 |
| | Accessories | |
| | Replacement kits | |
| | Automatic document feeder and scanner assembly | |
| | Assembly locations (1 of 2) | |
| | Assembly locations (2 of 2) | 344 |
| | Covers | 346 |
| | Internal assemblies | 350 |
| | Printed circuit assemblies (PCAs) | 380 |
| | Alphabetical parts list | 382 |
| | Numerical parts list | 399 |
| Inde | ex | 417 |
| | | |